


# MotoJob

PC application for automatic transfer of robot jobs between robot controllers and an external storage.



## Automated robot job transfer

MotoJob is a PC application for automated transfer of robot jobs between an external computer storage and the robot controller. The transfer is initiated by the robot controller with a preconfigured trigger variable and value. The MotoJob PC application uses a return trigger to signal back to the robot controller that the transfer is done.

Use MotoJob for a one-way transfer from external storage to the robot, or as a two-way transfer where robot jobs are sent to the external storage as a backup after use. Robot jobs can be selected one by one, grouped per directory or part numbers.

## Key benefits

- Ideal for offline programming.
- Unlimited number of robot controllers.
- Select robot jobs by name, directory, or part number.

## Compatible with

NX100, DX100, FS100, DX200,  
YRC100 and YRC1000micro.

